

MAGLATCH

Compliance Without Compromise



MagLatch DD5V1

MagLatch has two modes. Free State and Ban State. MagLatch is to be used in Ban State mode when under state regulation that prohibits detachable magazines with "evil features." Evil features include but are not limited to pistol grips, collapsible stocks, or flash hiders. To switch between modes simply separate your upper and lower receiver and rotate the set screw then reassemble firearm. **With MagLatch DD5V1 rotated clockwise** you are in Ban State mode. **With MagLatch DD5V1 rotated counter-clockwise** you are in Free State mode. If using Free State mode while in a ban state you have constructed an illegal "Assault Weapon." By installing this device, the user of this product assumes all risks and liabilities. MagLatch and its affiliates are not responsible for the action or improper use of this product by the user.

MagLatch has not been approved by the CA DOJ. This device is designed to conform to the law as written in SB-880/AB 1135 which would define "fixed magazine" to mean an ammunition feeding device contained in, or permanently attached to, a firearm in such a manner that the device cannot be removed without disassembly of the firearm action.

INSTALLATION INSTRUCTIONS

Please read through all of the instructions before attempting install.

If necessary consult a qualified gunsmith to complete the install.

Before beginning, make sure your firearm is unloaded and chamber is clear.

- Depress the rear takedown pin and front pivot pin and separate the upper and lower receivers. Put the upper receiver aside, only the lower receiver will be needed during installation.
- Remove existing magazine retention or bullet-button components. None of the existing parts will be used.
- Begin by inserting the MagLatch spring seat into the magazine catch orifice. Figure 1.
- Insert the provided dowel pin into the orifice above the backing block. Figure 2.
- Apply a drop of blue loctite and thread the provided set screw (not painted dog head set screw) into the orifice. Before tightening ensure the spring seat is slightly proud and parallel to the receiver surface. If it is crooked or cocked your release system will not work properly. Do not over-tighten set screw. Ensure it is flush with the receiver.
- Insert the provided magazine catch into the receiver thru the spring seat.
- Insert the provided magazine release spring on the opposite side of the receiver and seat it inside the spring seat.
- Thread the provided magazine release button onto the magazine catch. Depress the magazine release button and rotate the magazine catch approximately 3-4 turns or until the release button is at the proper depth.
- Insert a 10 Round magazine into the lower receiver.
- Thread the painted dog head set screw into the orifice behind the bolt catch until it bottoms out. Do not over-tighten. Figure 3.
- Test the magazine release assembly and ensure there is no movement or your magazine is "fixed."
- Reassemble your upper and lower receiver.



Figure 1



Figure 2



Figure 3

MODES OF MAGLATCH DD5V1:

- BAN STATE: Rotate dog head set screw clockwise until contact is made.
- FREE STATE: Rotate dog head set screw counter-clockwise 1.5-2 turns.