MAGLATCH

Compliance Without Compromise

MagLatch M1A/M14

MagLatch has two modes. Free State and Ban State. MagLatch is to be used in Ban State mode when under state regulation that prohibits detachable magazines with "evil features." Evil features include but are not limited to pistol grips, collapsible stocks, or flash hiders. To switch between modes simply remove your trigger assembly and remove the device and reassemble firearm. **With MagLatch M1A** is Ban State mode. **Without MagLatch M1A** is Free State mode. If using Free State mode while in a ban state you have constructed an illegal "Assault Weapon." By installing this device, the user of this product assumes all risks and liabilities. MagLatch and its affiliates are not responsible for the action or improper use of this product by the user.

MagLatch has not been approved by the CA DOJ. This device is designed to conform to the law as written in SB-880/AB 1135 which would define "fixed magazine" to mean an ammunition feeding device contained in, or permanently attached to, a firearm in such a manner that the device cannot be removed without disassembly of the firearm action.

INSTALLATION INSTRUCTIONS

Please read through all of the instructions before attempting install.

If necessary consult a qualified gunsmith to complete the install.

Before beginning, make sure your firearm is unloaded and chamber is clear.

- Unlatch trigger guard by using the optional take down tool or your preferred method.
- Slide MagLatch M1A behind the magazine release and onto the trigger housing (Figure 1). Slide MagLatch as far down as possible behind the magazine release lever.
- If the device does not fit onto the trigger housing either open or close with a pair of pliers to fit. It should fit snugly and not move around.
- Reinstall the fire control group back into the rifle. Before latching the trigger guard insert a magazine and operate the magazine release to ensure the magazine is fixed. Once verified, relatch the trigger guard.

Figure 1

MODES OF MAGLATCH M1A:

- BAN STATE: Insert MagLatch M1A behind magazine release lever.
- FREE STATE: Remove MagLatch M1A. Use the hole to attach to your keychain to prevent loss.